



MODEL PFC3001-XXX-XXXX

User's Manual

Power Factor Correction Module

This manual covers the use and maintenance of the model PFC3001 series Module.

Title: PFC3001 User Manual
Installation and Operation

Type of Documentation: User Hardware Manual

Document Type code: UM Rev 1.0 09-18-09.doc

Internal File Reference: Document Number: A10469

Purpose of Documentation: This documentation describes...

- Installation and operation of the PFC3001 drive.

Record of Revisions:

RELEASE NUMBER	DATE	DESCRIPTION	COMMENTS
1.0	09/18/09		Initial Release

Copyright: ©2009 ElectroCraft MI, Inc USA. All rights Reserved.

Copying this document, giving it to others and the use or communication of the contents there of without express authority, is forbidden. Offenders are liable for the payment of damages. We reserve the right to modify our products at any time. Information, specifications, and material data that appear within this user manual are subject to change without notice. For the latest revision of this manual, please check our web site or contact ElectroCraft.

Validity: The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product

Published by: ElectroCraft MI, Incorporated
P.O. Box 7746, Ann Arbor, Michigan 48108 USA

Tel.: 734-662-7771 • Fax: 734-662-3707
<http://www.electrocrafter.com>

Table of Contents

1	PFC3001 Controller	4
1.1	Overview	4
2	PFC3001 Introduction	5
2.1	Theory of Operation	5
3	Product Safety Precautions	6
3.1	Operation	6
3.2	Storage and Transportation	8
3.3	Installation	8
3.4	Wiring	9
3.5	Life Support Policy	9
4	Checking Product on Delivery	10
5	Recommended Cabling and Installation	11
6	PFC3001 Installation and Setup	12
6.1	Mounting the PFC3001	13
6.2	Environmental Conditions	13
6.3	Simplified PFC3001 Block Diagram	14
6.4	PFC3001 Connector Description	15
6.4.1	J1: AC Power In	15
6.4.2	J2: DC Power Out	15
6.4.3	J3: I ² C Communication	15
7	PFC3001 Status LED's	16
7.1	Status	16
7.2	I ² C Communication	17
8	I²C message Protocol	18
8.1	Description	18
8.2	Physical Connections	18
8.3	Addressing	18
8.4	Read / Write	19
8.5	Status Byte Definition	19
8.6	AC Line Definition	20
9	Overload Protection	21
10	First Time Operation	22
10.1	PFC3001 Electrical Ratings	23
11	PFC3001 Dimensional Drawing	24
12	List of Mating Connectors	26
13	Model Identification	27

1 PFC3001 Controller

This manual describes the installation and operation of the PFC3001 Power Factor Correction Module manufactured by ElectroCraft MI, Inc.

1.1 Overview

ElectroCraft's PFC3001 series modules will help eliminate servo-amplifier current flow problems.

The PFC3001 Module:

- High power factor (>.99 at full load)
- Reduced line harmonics
- Fully regulated DC output, 395 min. to 420 VDC max.
- Available for power levels up to 3500 watts
- Compact surface mount design: 7.88" X 3.15" X 5.85"
- Available input ranges of 175 to 262 VAC-RMS, 48-62 Hz
- Reduced peak charging current resulting in improved capacitor reliability
- Designed to be compliant with EN61000-3-2 international power harmonics standard
- Smaller bulk capacitor size and reduced cost
- Compact package size.

The remainder of this page is intentionally left blank.

2 PFC3001 Introduction

2.1 Theory of Operation

The ElectroCraft module attenuates AC line harmonics induced by switching power amplifiers and prevents overloading of neutral conductors and transformers.

AC line operated servo-amplifiers employ full wave rectification with capacitor input filtering for motor rail power. They draw current in short, high amplitude bursts near the peak of the line voltage sinusoid. This can result in cost penalties, especially at higher power. Excessive peak current flow may be imposed on the AC line service leading to limits on the power available and requiring costly increases in the AC service capability (assuming this is even practical).

Power factor correction (PFC) is required in any motion control application demanding optimum utilization of available line currents and/or minimum line current distortion. An ElectroCraft PFC3001 module can give the system more power without increasing line capacity and offers reliable operation while reducing peak AC current input needs

The remainder of this page is intentionally left blank.

3 Product Safety Precautions

READ THIS ENTIRE SECTION BEFORE ATTEMPTING TO USE THE ACE SERVO DRIVE! GIVE SPECIAL ATTENTION TO ALL BOLD PRINT ITEMS.



WARNING!

THIS PRODUCT USES HIGH VOLTAGE ELECTRIC POWER AND POSES A SHOCK HAZARD TO THE USER.



To operate your control successfully, these minimum safety precautions **MUST** be followed to insure proper performance without injury to the operator and damage to motor or control. **FAILURE TO OBSERVE THESE SAFETY PRECAUTIONS COULD RESULT IN SERIOUS BODILY INJURY, INCLUDING DEATH IN EXTREME CASES.**

3.1 Operation

1. Do not touch any of the output connector pins from connectors J1, or J2 when power has been applied. The voltages at these connector pins are dangerous and can produce an electric shock. Bare wires from adjacent connector pins must never be allowed to touch one another.
2. The ground screw must be connected to an external earth ground. Follow wiring procedures carefully. Know and understand which connectors are NOT electrically isolated from the AC/DC voltages within the drive.
3. Always operate the PFC3001 within the prescribed voltage limits. Any attempt to operate outside these bounds may result in damage to the unit.
4. Read ElectroCraft's Life Support Policy in section 3.5 for application limitations.
5. Do not operate the PFC3001 in an explosive area or near explosive or flammable materials.
6. Do not use the PFC3001 in environments where it is likely to be exposed to strong and/or frequent static discharge.
7. Short circuit protection for the PFC3001 is limited to internal fuses for J1.
8. Short circuits on any of the output pins for J2 will likely cause permanent damage to the PFC3001
9. Do not turn the PFC3001 on or off frequently unless necessary. Failure to observe this caution may cause internal parts to deteriorate.
10. Avoid plugging connector J1 into the PFC3001 while live power is applied to the connecting cables. Ignoring this precaution will cause electrical arcing at the connector pins, which can cause permanent connector damage.

11. Do not remove the cover if one has been supplied. If no cover was supplied DO NOT touch any internal parts while live external AC power is applied to the PFC. Each model has dangerous voltages on the circuit board and may store a high voltage charge for several minutes after being disconnected.
12. Do not damage, press, exert excessive force or place heavy objects on the cables. Failure to observe this warning may result in electric shock, stopping operation of the product, or burning.
13. Do not service or modify this product. Only authorized personnel must perform disassembly or repair of the PFC3001. Failure to observe warning may result in injury or damage to product.
14. To avoid a shock hazard always wait at least 10 minutes after disconnecting power from J1 before physically touching any internal circuits or external terminals. Residual voltage may cause electric shock. If necessary, use a functioning voltmeter to be certain that all high voltage capacitors inside the PFC3001 are fully discharged before physically touching internal circuits or external terminals.

The remainder of this page is intentionally left blank.

3.2 Storage and Transportation

1. Do not store or install the product in the following place
 - a. Locations subject to temperature outside of the range specified.
 - b. Locations subject to humidity outside the range specified.
 - c. Locations subject to condensation as the result of extreme changes in temperature.
 - d. Locations subject to corrosive or flammable gases and liquids.
 - e. Locations subject to dust, salts, or iron contaminants.
 - f. Locations subject to exposure to water, oil, or chemicals.
 - g. Locations subject to shock or vibration.

Failure to observe this caution may result in fire, electric shock, damage to the product.

2. Do not hold the product by the cables while transporting it. Failure to observe this caution may result in injury or malfunction.
3. Store the PFC3001 drive, when not in use, in temperatures between -20 to +85 degrees C.

3.3 Installation

1. Take appropriate and sufficient countermeasures when installing systems in the following locations.
 - a. Locations subject to static electricity or other forms of noise.
 - b. Locations subject to strong electromagnetic fields and magnetic fields.
 - c. Locations subject to possible exposure to radioactivity.
 - d. Locations close to power supplies including power lines.

Failure to observe this caution may result in damage to the product.

2. Never use this product in an environment subject to liquids, corrosive chemicals or gases, or combustibles, or where foreign materials are allowed to fall onto or collect inside the drive
Failure to observe this caution may result in electric shock or fire.
3. Do not place heavy objects on the product. Failure to observe this warning may result in stopping operation of the product.
4. Do not cover or prevent air from escaping or entering through the vents with obstruction or foreign object. Failure to observe this caution may cause internal elements to deteriorate resulting in malfunction or fire.
5. Provide the specified clearance between the PFC3001 and the control panel or with other devices. Provide sufficient space around the PFC3001 for cooling by natural convection or provide cooling fans to prevent excessive heat. Failure to observe this caution may result in fire or malfunction.

3.4 Wiring

1. Verify **ALL** wiring **BEFORE** applying power to the control and motor. PFC3001 may be damaged or improper wiring may prevent drive from operation.
2. The frame ground screw **MUST** always be mechanically and electrically connected to an appropriate external earth ground.
3. Connect the ground screw to the electrical codes (ground resistance should be less than 10 ohms. Improper grounding may result in electric shock or fire.
4. Do not connect three-phase power to J1. Failure to observe this caution may result in injury or fire.
5. Securely connect the power supply terminals and output terminals. Failure to observe this caution may result in fire.
6. Do not bundle or run power and signal lines together in the same duct. Keep power and signal lines separated by at least 30cm.
7. Always use the specified power supply voltage. An incorrect voltage may result in burning. Be particularly careful where the power supply is unstable. An incorrect power supply may result in damage to the product.
8. Install external breakers or other safety devices against short-circuiting in external wiring. Failure to observe this caution may result in fire or damage to the PFC3001.

3.5 Life Support Policy

**READ THIS ENTIRE SECTION BEFORE ATTEMPTING TO USE THE PFC3001!
GIVE SPECIAL ATTENTION TO ALL BOLD PRINT ITEMS.**

ElectroCraft's products are not authorized for use as critical components in life support devices or systems without the express written approval from ElectroCraft MI, Incorporated.

1. Life support devices or systems, are devices or systems which are intended for surgical implant into the body, or support or sustain life, and whose failure to perform, when properly used in accordance with instructions for use provided in the User's Manual and in the labeling, can be reasonable expected to result in a significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

4 Checking Product on Delivery

When your package arrives, inspect the shipping box and the unit carefully, and save ALL packing materials. Compare the packing slip against all items included in the shipping box. Any shortages or other inspection problems should be reported to ElectroCraft immediately.

The following procedure is used to check products upon delivery. Check the following items when your PFC3001 is delivered.

- Verify that the model number marked on the nameplate of the drive(s) is the correct model ordered.
- Check the overall appearance. Check for damage or scratches that may have occurred during shipping.

If any damage, or if the unit is the wrong type, contact your ElectroCraft sales representative immediately.

Your PFC3001 has arrived carefully packaged from ElectroCraft MI. As you unseal this bag, inspect the contents carefully. There should not be any loose or damaged parts inside.


Never attempt to operate or power-up the PFC3001 if there is any visible external damage or if it sounds as though there are loose materials inside the chassis. While unpacking, if you discover any loose or damaged parts, notify ElectroCraft within two working days.

ElectroCraft recommends that all packing materials be saved in the event that the PFC3001 needs to be shipped back. Always place the PFC3001 in the same antistatic bag used in the original shipment. Abundant anti-static filler material should always be placed around the PFC3001 so that it cannot shift inside the box. Extreme care should be exercised when placing packing material around all external connectors to prevent mechanical stress damage.

All material to be returned to ElectroCraft must have a Return Material Authorization (RMA) tracking number assigned before shipment. This may be obtained by contacting the ElectroCraft Service Dept. Any product returned without this number will be rejected by ElectroCraft.

Always insure your shipment for the proper replacement value of its contents. ElectroCraft will not assume responsibility for any returned goods that have been damaged outside of our factory because of improper packaging or handling. All goods shipped to ElectroCraft must be shipped FREIGHT PREPAID.

5 Recommended Cabling and Installation



6 PFC3001 Installation and Setup



READ ENTIRE USER MANUAL FIRST BEFORE ATTEMPTING TO USE THIS PRODUCT.

If you require further assistance than provided within this manual, please email, call, or fax:

ElectroCraft MI, Incorporated®

**P.O. Box 7746
Ann Arbor, MI USA 48107**

**(734) 662-7771
Fax #(734) 662-3707**

www.electrocraft.com

This chapter presents installation procedures and instructions on how to setup your PFC3001 drive.



WARNING!

HIGH VOLTAGE MAY BE PRESENT AT THE J2 CONNECTOR.



If the user adds supplemental external capacitance via terminal J2, provisions should be made by the user to rapidly bleed this high voltage energy down to safe levels whenever the user's power source is disconnected from the system. Bleeder resistors are frequently used for this purpose. It will be necessary for the user to size this discharge method appropriately. The objective is to reduce the rail voltage down to safe levels (generally below +40 Volts DC) within an acceptable time period after the user's external power source is turned off or disconnected.

6.1 Mounting the PFC3001

Use this preferred hardware type, see table below, for mounting your PFC3001 drive. Mount your PFC3001 in the following manner.

Base Mounted	Six M4 screws. Include spring (locking) washer with plain washer.	Customer supplied
--------------	---	-------------------

Weight: 3.43Kg (7.56)

Size: 8.56" (218mm) x 8.4" (213mm) x 4.13" (105mm) with heatsink.

6.2 Environmental Conditions in the Control Panel

- Storage Temperature: -20-85 degree C
- Humidity: 5-95%RH, Non-condensing
- Operating Temperature range: 0-50 degree C
- Vibration: Install a vibration isolator beneath the drive to avoid subjecting it to vibration.

The remainder of this page is intentionally left blank.

6.3 Simplified PFC3001 Internal Block Diagram

This following diagram is provided to familiarize the user with the internal architecture of the PFC3001.




Figure 1: PFC3001 Block Diagram

6.4 PFC3001 Connector Description

For visual reference to the PFC3001 connectors, see Figure 2 below.




Figure 2: PFC3001 Connector Layout

6.4.1 J1 Connector: AC Power Input, plug

Pin #	I/O	Description
1	AC Input	185 to 254 VAC, 50/60 Hz, 1 Phase AC
2	n/a	No connect.
3	AC Input	185 to 254 VAC, 50/60 Hz, 1 Phase AC

*17 Amperes maximum rated current demand.

6.4.2 J2 Connector: DC Power Output, plug.

Pin #	I/O	Description
1	Output	<u>Output Bus Voltage</u> : 395 to 420 DC Volts. 7.5 ampere nominal rated full load current.
2	Output	<u>Common Return</u>

6.4.3 J3 Connector: I²C Communications, plug.

Pin #	I/O	Description
1		Shutdown
2	I/O	Data (SDO)
3	I/O	Clock (SCL)
4	Input	Common (Return from user supplied +5V)
5		Direct connection between ports A and B
6		Direct connection between ports A and B
7	Input	+5VDC (user supplied)
8		Direct connection between ports A and B

7. PFC3001 Status LED's

7.1. Internal Status LED (Green)

LED	Description	Possible Cause	Result	Recovery Method
Off steady	Processor is inoperable.	<ul style="list-style-type: none"> Possible RAM error. Processor not running. Faulty on-board +5V supply. 	<ul style="list-style-type: none"> PFC will stay in STANDBY mode. Processor code branches to dead-end program loop in order to prevent any PFC operation. 	<ul style="list-style-type: none"> Disconnect power from the PFC for 1 min to reset the microprocessor. Then re-apply power to allow microprocessor to operate.
On Steady	PFC is in RUN mode. +400VDC boost is enabled.	<ul style="list-style-type: none"> User commanded RUN mode via I²C interface 	<ul style="list-style-type: none"> Clear all faults and STATUS flags. Enable +400VDC boost output. 	N/A
1	PFC is in STANDBY mode. +400VDC boost is disabled.	<ul style="list-style-type: none"> Initial power up. User commanded via I²C communications link. WatchDog timeout. 	<ul style="list-style-type: none"> Set STANDBY STATUS bit. PFC is placed into STANDBY mode. Clear all faults and STATUS flags. 	<ul style="list-style-type: none"> Command RUN mode via the I²C interface.
2	SCI communications timeout detected.	<ul style="list-style-type: none"> Lost synchronization between processors. Communications processor was placed in reset. WatchDog timeout on communications processor 	<ul style="list-style-type: none"> Set STANDBY STATUS bit. Set SCI Error STATUS bit. PFC is placed into STANDBY mode. 	<ul style="list-style-type: none"> Reset User Communications microprocessor by placing the I²C Shutdown signal into a logic '0' state for 100mS, then back to a logic '1'. Command RUN mode via the I²C interface.
3	+400VDC output has dropped below +385VDC.	<ul style="list-style-type: none"> Excessive load on PFC. PFC unable to regulate +400VDC output. 	<ul style="list-style-type: none"> Set STANDBY STATUS bit. Set +400V STATUS bit. PFC is placed into STANDBY mode. 	<ul style="list-style-type: none"> Check for excessive loading. Command RUN mode via the I²C interface.
4	B+ rail was detected to be out of range. Normal operating range is +175VAC RMS to +264VAC RMS.	<ul style="list-style-type: none"> B+ rail detected to be below +175VAC RMS. User commanded RUN mode when B+ rail was below +185VAC RMS. B+ rail detected to be above +264VAC RMS. 	<ul style="list-style-type: none"> Set STANDBY STATUS bit. Set B+ STATUS bit. PFC is placed into STANDBY mode. 	<ul style="list-style-type: none"> Check that AC input voltage is above +185VAC RMS and below +264 VAC RMS. Check for excessive loading. Command RUN mode via the I²C interface.
5	+18VDC supply was detected to be out of range. Normal operating range is +17VDC to +19VDC.	<ul style="list-style-type: none"> +18VDC supply detected to be below +17VDC. +18VDC supply was detected to be above +19VDC. 	<ul style="list-style-type: none"> Set STANDBY STATUS bit. Set +18V STATUS bit. PFC is placed into STANDBY mode. 	<ul style="list-style-type: none"> Disconnect power from the PFC for 1 min to reset the microprocessor. Then re-apply power to allow microprocessor to operate. Command RUN mode via the I²C interface.
6	PFC was detected to be in an overload condition.	<ul style="list-style-type: none"> PFC AC line current above 12 Amps and below 15 Amps for 1 hr. PFC AC line current above 15 AMPS for 30 min. 	<ul style="list-style-type: none"> Set Overload STATUS bit to notify User. If condition exists for more than 2 minutes, PFC is placed into STANDBY mode. STANDBY STATUS bit is set. 	<ul style="list-style-type: none"> Command STANDBY mode via the I²C interface. Reduce AC line current to below 12A RMS.
7	PFC was detected to be in an over temperature condition.	<ul style="list-style-type: none"> Heatsink temperature exceeded N degrees C 	<ul style="list-style-type: none"> Set STANDBY STATUS bit. Set Overtemp STATUS bit. PFC is placed into STANDBY mode. 	<ul style="list-style-type: none"> Allow adequate time for PFC to cool down. Command RUN mode via the I²C interface.
Flicker/Dim	Internal Memory Error	<ul style="list-style-type: none"> Possible RAM error. Processor not running. Faulty on-board +5V supply. 	<ul style="list-style-type: none"> PFC will stay in STANDBY mode. Processor code branches to dead-end program loop in order to prevent any PFC operation. 	<ul style="list-style-type: none"> Disconnect power from the PFC for 1 min to reset the microprocessor. Then re-apply power to allow microprocessor to operate.

7.2. I²C Communications LED (Red)

LED	Description	Possible Cause	Result	Recovery Method
Off steady	Processor is in Reset or inoperable. No communications are possible in this mode.	<ul style="list-style-type: none"> User commanded an I²C shutdown (I²C Shutdown input = logic 0). Intermittent I²C connection or loss of user supplied +5V. Possible RAM error. Processor is not running. 	<ul style="list-style-type: none"> If user commanded an I²C shutdown, processor is held in RESET state. User interface may not be powered. If processor error, processor is either not running or stuck in a dead-end RAM error loop in order to prevent any PFC operation. 	<ul style="list-style-type: none"> Force a hardware reset of the microprocessor by placing I²C Shutdown signal into a logic '0' state for 100mS then into a logic '1' state. Check I²C connections. Verify user supplied +5VDC is present. If processor error, PFC must be serviced.
On Steady	Processor is operating and ready to communicate with user.	<ul style="list-style-type: none"> User commanded to allow I²C communications (I²C Shutdown input = logic 1). 	<ul style="list-style-type: none"> Processor initialized and communications enabled. 	N/A
None (On Steady)	I ² C timeout error detected.	<ul style="list-style-type: none"> Interruption during I²C communications. Incomplete I²C communication. I.e. Improper use of ACK bit, premature clock termination, etc. 	<ul style="list-style-type: none"> I²C STATUS bit set. PFC is placed into STANDBY mode. STANDBY bit is set. 	<ul style="list-style-type: none"> Force a hardware reset of the microprocessor by placing I²C Shutdown signal into a logic '0' state for 100mS then into a logic '1' state. Check I²C connections. Verify user supplied +5VDC is present.

The remainder of this page is intentionally left blank.

8. I²C Message Protocol

8.1. Description

The I²C bus is a bi-directional communication interface. Two wires, serial data (SDA) and serial clock (SCL), carry information between devices connected to the bus. Each device is recognized by a unique address and can operate as either a transmitter or receiver. Devices can also operate as either a master or a slave. A master is the device which initiates a data transfer on the bus and generates the clock signals to permit that transfer. At that time, any device addressed is considered a slave. In this implementation, the PFC is always a slave.

Both SDA and SCL are bi-directional lines, connected to a positive supply voltage via a pull-up resistor. When the bus is free, both lines are HIGH. The output pins connected to the bus are open-collector in order to perform the wired-AND function. Data on this implementation of the I²C bus can be transferred at a rate up to 100 kbit/s.

For more information on I²C, see the I²C specification by Philips Semiconductors.

8.2. Physical Connections

Connections for the I²C bus are as follows:

I ² C Signal	PFC Connection
Shutdown	J3 pin 1
Data (SDO)	J3 pin 2
Clock (SCL)	J3 pin 3
Ground (return for user supplied +5VDC)	J3 pin 4
+5VDC (user supplied)	J3 pin 7

Note: The pin-out is the same for both A & B ports on the dual RJ45 connector. Also, all other pins on J3 are a straight through connection from port A to port B.

8.3. Addressing

7 bit Addressing

The PFC's address will be 0x3C (write operations) or 0x3D (read operations).

10 bit Addressing

The PFC will ignore all 10 bit addresses.

8.4. Read / Write

Read commands

All read operations will result in the transfer of the STATUS byte, AC line current, and B+ rail voltage (in this order). The user may choose to read one, two, or all three bytes during a read operation. The first data byte read from the PFC during any read operation will be the STATUS byte.

Write commands

All write operations to the PFC will consist of one data byte. If more than one byte is written to the PFC, the PFC will ignore the additional bytes. Also, if the drive is addressed for writing and no byte is sent, the PFC will detect an I²C communications error.

Only one bit should be set in the command byte. If more than one bit is set or if no bits are set, the PFC will ignore the command.

Command Bit #	Description
0	Place PFC into Standby mode
1	Place PFC into Operational mode
2	Reserved, should always be cleared to '0'
3	Reserved, should always be cleared to '0'
4	Reserved, should always be cleared to '0'
5	Reserved, should always be cleared to '0'
6	Reserved, should always be cleared to '0'
7	Reserved, should always be cleared to '0'

Note: A "1" in the Command byte indicates an action to be taken.

8.5. Status Byte Definition

All status information about the PFC is contained in a one byte Status byte.

Status Bit #	Description
0	PFC in STANDBY mode
1	On-Board SCI Error
2	+400 VDC Supply Fault
3	B+ Fault
4	+18V Supply Fault
5	PFC Overload
6	PFC Over Temperature
7	I ² C Communication Error

Note: A "1" in the STATUS word indicates an active condition.

8.6. AC Line Current / B+ Rail Voltage Definition

Sampling Method

The AC line current is sampled 4 times a second. B+ rail voltage is sampled approximately once each millisecond. The resulting A/D sample is added into a running average. A separate average is kept for AC line current as well as the bus voltage. The weighting of samples is as follows:

The most recent sample is taken at time t .

$$RunningAverage = \frac{1}{2} Sample_{(t)} + \frac{1}{4} Sample_{(t-1)} + \frac{1}{8} Sample_{(t-2)} + \frac{1}{16} Sample_{(t-3)} + \dots$$

The values for AC line current and B+ rail voltage that are supplied to the user are the *running average* values.

Scaling

AC line current is returned to the user via a single byte. The scaling of this byte is as follows:

$$AmpsRMS = AClinecurrent \times 0.0747436$$

B+ rail voltage is returned to the user via a single byte. The scaling of this byte is as follows:

$$BPlusVoltage = BPlusValue \times 1.484138$$

$$BPlusRMS = \frac{(BPlusVoltage + 1)}{1.4142}$$

9. Overload Protection

The PFC Monitor microprocessor will act upon the AC line current measurement once per minute. Based on the amount of current being drawn from the AC line, heating of the inductor (L1) can be predicted. Using the *Running Average* (see above) AC line current value, a counter value is either increased or decreased based upon the threshold values below.

- If PFC is in STANDBY mode, decrement OverLoad counter by 2 (for a 30 min cool-down).
- If $0 \leq \text{line current} < 12\text{A}$, decrement OverLoad counter by 1 (for a 60 min cool-down).
- If $12\text{A} \leq \text{line current} < 15\text{A}$, increment OverLoad counter by 1 (for a 60 min heat-up).
- If $15\text{A} \leq \text{line current} < 17\text{A}$, increment OverLoad counter by 2 (for a 30 min heat-up).
- If $\text{line current} \geq 17\text{A}$, increment OverLoad counter by 12 (for a 5 min heat-up).

Once the variable OverLoad counter reaches 60, the overload bit in the PFC STATUS byte is set. This warns the user that the PFC will shut itself down in one minute if current draw is not reduced to below 12A. In the next sample period (1 minute later), if the variable OverLoad counter is still at 60, the PFC will shut down and go into a self imposed STANDBY mode. If the variable OverLoad counter is < 60 , the overload status bit will be cleared and the PFC will not shutdown.

The above thresholds for incrementing and decrementing the OverLoad counter will always apply. For example: If the PFC detects an overload condition and enters a self imposed STANDBY mode, the OverLoad counter will decrement by 2 each minute (for a 30 min. cool down). Likewise, if the user is warned of an overload and the current draw is reduced to below 12A, when the next sample is taken (1 min. later), the OverLoad counter will decrement according to the above thresholds.

The remainder of this page is intentionally left blank.

10. First Time Operation

1. It is recommended that all interconnecting cables be kept as short as possible between the PFC and other system components.
2. The PFC unit must be heat sunk before use. ElectroCraft recommends using the finned aluminum heatsink supplied with the unit, or the PFC should be mounted to a cold plate. Under maximum load conditions the PFC can develop as much as 200 Watts of energy loss on its backplane. Without proper heat sinking the PFC could be damaged under high loads.
3. A minimum of 14AWG wire for all power interconnecting cables to and from the PFC are required. Teflon insulation is recommended over PVC for all power cables. If shielded cables are to be used for connections to the PFC ports J1 and J2, then terminate the shield to ground.
4. A single point ground is required for the PFC, servo drive and external EMI filter. All grounds for these three components should terminate in only one location.
5. Do not disconnect and reconnect loads to the PFC while it is powered. All cables to the PFC should be installed before any external AC power is applied to connector J1.
6. The PFC is internally fused. Normally these fuses should never need replacement. If a fuse does ever blow, please consult with ElectroCraft first before replacing it.

The remainder of this page is intentionally left blank.

10.1. PFC3001 Electrical Ratings

Ratings at Temperatures = 0...50°C, (unless otherwise noted)

Parameter	Conditions	Value	Units
Supply			
Supply voltage	Nominal operating (single phase)	175 to 254	VAC
Supply current, surge	Inrush pulse duration <=100mS		A
Supply current, idle	No load condition.		mA
Supply current, operating			A
Output voltage	Normal	395 to 420	VDC
Output Power	Continuous	2400	W
Output Power	Peak / Momentary	3500	W
Other			
Thermal resistance	Case to ambient		°C/W
Frame isolation voltage withstand	GND to Frame.	4000	VAC / Minute
Operating temperature	powered	0 to +50	°C
Storage temperature	Not powered	-20 to +85	°C
Humidity	Non-condensing	5 to 95	%RH
Weight		7.56 / 3.43	Lb./Kg

The remainder of this page is intentionally left blank.

11. PFC3001 Dimensional Drawing

Units: mm [in]




Figure 3: PFC3001 Package Outline – Side/Top View

PFC3001 Dimensional Drawing, continued

Units: mm [in]




Figure 4: PFC3001 Package Outline – Front View

12 List of Mating Connectors

Ref.	Connector name	Manufacturer	DESCRIPTION	P/N
J1	Power In	AMP / TYCO	Mate-N-Lok Plug	350766-1
			Socket (pins)	350550
J2	Power Out	AMP / TYCO	Mate-N-Lok Plug	350777-1
			Socket (pins)	350550-7
J3	I ² C Communications	Assmann Electronics	8P8C RJ45 Plug	A-MO-8/8-SF

The remainder of this page is intentionally left blank.

13 Model Identification

